

Sliding Bearings

Part 1


21 December 2010

Prof. Samy J. Ebeid

1

Viscosity

Consider:
A moving plate by force P .
A stationary plate.
A lubricant in between.
The two plates are parallel.




21 December 2010

Prof. Samy J. Ebeid

2

Viscosity



The particles of the lubricant adhere strongly to the moving and stationary plates.


Motion is accompanied by a linear slip or shear between the lubricant layers.

21 December 2010

Prof. Samy J. Ebeid

۳

Viscosity



Newton found that:


The magnitude of the shearing stress varies directly with the velocity of the moving plate.
The magnitude of the shearing stress varies inversely with the film thickness h .

21 December 2010

Prof. Samy J. Ebeid

۴

Viscosity



When the two plates are parallel:

1 The velocity is proportional to the distance from the stationary plate.

2


3

21 December 2010

Prof. Samy J. Ebeid

◦

Viscosity



When the two plates are inclined:

1

2

21 December 2010

Prof. Samy J. Ebeid

1

Viscosity

1. Absolute Viscosity or Dynamic Viscosity

| Method of Representation | | |
|--------------------------|---|---|
| Reyn after Reynolds | Poise after Poiseuille | SI metric units |
| Lbf sec/in ² | Dyne sec/cm ² | Ns/m ² |
| | 1 kg = 9.8 * 10 ⁵ dyne 1 kg = 9.8 N | Poiseuille (PI) = 1 Ns/m ² |
| | | 1 P = 0.1 PI = 0.1 Ns/m ² 1 cP = 0.01 P = 0.001 Ns/m ² |
| | | P = Poise cP = Centipoise |

21 December 2010

Prof. Samy J. Ebeid

v

Viscosity

2. Kinematic Viscosity

| Method of Representation |
|--|
| Stokes m ² /s |
| 1 St = 10 ⁻⁴ m ² /s |
| 1 cSt = 10 ⁻⁶ m ² /s |

Relationship between Dynamic and Kinematic Viscosities

$$Z = \nu * \gamma / g$$

Z = Dynamic or Absolute Viscosity, Ns/m²

ν = Kinematic Viscosity, m²/s

γ = Density, N/m³, (average value = 0.85-0.90 g/cm³)


g in m/s²

21 December 2010

Prof. Samy J. Ebeid

^


Friction



Dry Friction:
1

21 December 2010
Prof. Samy J. Ebeid
9


Friction




Semi-Dry Friction:
1 Absence of any added lubricant.

21 December 2010
Prof. Samy J. Ebeid
10

Friction







Boundary Friction:
1

21 December 2010
Prof. Samy J. Ebeid
١١

Friction







Fluid Friction:
1 Presence of a complete film of lubricant.

21 December 2010
Prof. Samy J. Ebeid
١٢

Lubrication

Wedge Action Principle




21 December 2010

Prof. Samy J. Ebeid

١٣

Assembly of a Bush




21 December 2010


Prof. Samy J. Ebeid

١٤

Bearing Bushes – Journal Bearing



Simple Bush



Bush with Shoulder

Materials:

Cl, PhBr, Plastics, ..


21 December 2010

Prof. Samy J. Ebeid


١٥

Bearing Bushes

Bush Housing



Anti-friction Material




21 December 2010

Prof. Samy J. Ebeid

١٦

Lubrication




21 December 2010

Prof. Samy J. Ebeid

١٧

Lubrication




21 December 2010

Prof. Samy J. Ebeid

١٨

Hydrodynamic Action




21 December 2010

Prof. Samy J. Ebeid

١٩

Shaft just *Starting* to Rotate




21 December 2010

Prof. Samy J. Ebeid

٢٠

Hydrodynamic Action (Rotating Shaft)




21 December 2010


Prof. Samy J. Ebeid

٢١

Shaft just *Starting* to Rotate



Hydrodynamic Action (Rotating Shaft)




21 December 2010

Prof. Samy J. Ebeid

٢٢

Hydrodynamic Action

(radial pressure distribution)




21 December 2010

Prof. Samy J. Ebeid

٢٣

Hydrodynamic Action

(axial pressure distribution due to shaft errors)



21 December 2010


Prof. Samy J. Ebeid

٢٤

Bearing Dimensionless Ratios

1

Breadth ratio: β



$\beta = 0.6 - 1.5$ Normal loading
 $0.4 - 0.6$ Heavy loading

21 December 2010


Prof. Samy J. Ebeid

٢٥

Bearing Dimensionless Ratios

2

Clearance ratio: ψ



| | |
|--------------------------|--------------------------------------|
| $\psi = 0.0020 - 0.0030$ | High speed and Moderate pressure |
| $0.0015 - 0.0025$ | High speed and High pressure |
| $0.0007 - 0.0012$ | Very low speed and Moderate pressure |
| $0.0003 - 0.0006$ | Very low speed and High pressure |

21 December 2010


Prof. Samy J. Ebeid

٢٦

Bearing Dimensionless Ratios

3

Eccentricity ratio: ϵ



$\epsilon = 0.7 - 0.9$ Normal loading
 $0.5 - 0.7$ Heavy loading

21 December 2010

Prof. Samy J. Ebeid


٢٧

Pressure Distribution Equation

p = Pressure at any point on the parabola

p_0 = Max parabola pressure

$m =$



21 December 2010

Prof. Samy J. Ebeid

٢٨

Pressure Distribution Equation

p_0 = Max parabola pressure

Π_0 =

Z = Absolute or Dynamic Viscosity


ψ = Clearance Ratio

ω = Angular Velocity

21 December 2010

Prof. Samy J. Ebeid

٢٩



Pressure Distribution Equation

p_m =

Π_m = Dimensionless Parameter

Z = Absolute or Dynamic Viscosity


ψ = Clearance Ratio

ω = Angular Velocity

21 December 2010

Prof. Samy J. Ebeid


٣٠



Pressure Distribution Equation

$$\Pi_m = p_m \cdot \frac{\psi^2}{Z \cdot \omega}$$

Π_m (N/m²)
 p_m (Ns/m²)
 Z (Rad/s)
 ω (Rad/s)



21 December 2010

Prof. Samy J. Ebeid

٣١

Bearing Characteristic Number

Various investigators, employing dimensional analysis, have shown that the journal coefficient of friction is a function of at least three dimensionless parameters,

$$\frac{ZN}{p}, \frac{D}{C}, \text{ and } \frac{L}{D}$$

**All three parameters are
DIMENSIONLESS**


21 December 2010

Prof. Samy J. Ebeid

٣٢

Pressure Distribution Equation

Π_m is a function of



21 December 2010

Prof. Samy J. Ebeid

٣٣

Bearing Index Number Π_m

Values of Π_m versus β and ε

| ε | β | | | | | | | ε |
|---------------|---------|-------|-------|-------|-------|-------|--------|---------------|
| | 0.5 | 0.75 | 1.0 | 1.25 | 1.5 | 1.75 | 2.0 | |
| 0.1 | 0.0329 | 0.068 | 0.109 | 0.150 | 0.190 | 0.225 | 0.257 | 0.1 |
| 0.2 | 0.0697 | 0.143 | 0.226 | 0.311 | 0.391 | 0.463 | 0.526 | 0.2 |
| 0.3 | 0.115 | 0.233 | 0.365 | 0.496 | 0.618 | 0.727 | 0.822 | 0.3 |
| 0.4 | 0.117 | 0.351 | 0.540 | 0.724 | 0.892 | 1.040 | 1.167 | 0.4 |
| 0.5 | 0.268 | 0.518 | 0.728 | 1.029 | 1.259 | 1.439 | 1.599 | 0.5 |
| 0.6 | 0.415 | 0.779 | 1.148 | 1.477 | 1.759 | 1.996 | 2.192 | 0.6 |
| 0.7 | 0.679 | 1.236 | 1.771 | 2.219 | 2.585 | 2.881 | 3.117 | 0.7 |
| 0.8 | 1.253 | 2.208 | 3.062 | 3.720 | 4.221 | 4.601 | 4.891 | 0.8 |
| 0.9 | 3.134 | 5.320 | 7.118 | 8.339 | 9.167 | 9.731 | 10.120 | 0.9 |
| ε | 0.5 | 0.75 | 1.0 | 1.25 | 1.5 | 1.75 | 2.0 | ε |
| β | | | | | | | | |

21 December 2010

Prof. Samy J. Ebeid

٣٤

Pressure Distribution Equation

$$\Pi_m = p_m \cdot \frac{\psi^2}{Z \cdot \omega}$$

Π_m is a function of

Design Procedure

We can assume

When ω is known

But

Thus the design is completed

21 December 2010

Prof. Samy J. Ebeid

٣٥


Coefficient of Friction according to McKee

Z: kg.sec/sq.cm

p: kg/sq.cm

N: rpm

Always work in the



21 December 2010

Prof. Samy J. Ebeid

٣٦